


Important: Read safety information and instructions inside before using glue gun. Save all instruction sheets for future reference.

84015A Dual Temp / Mini Size / Glue Gun

Dual Temperature for High and Low temperature bonding.

High Temp: For Strong Bonding like Wood, Plastic, Metal, Glass & More

Low Temp: For Delicate Materials like Floral, Fabric, Foam, Jewelry & More



*Enhanced Safety Features


Safety Fuse: Shuts the glue gun off automatically in the event of a short.

Side Fins: Allows glue gun to lay safely on its side, preventing glue back up.

Insulated Nozzle: Helps safeguard against burns.

WARNING

When using electric tools, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify this plug in any way.

 **WARNING:** Cancer and Reproductive Harm - www.P65Warnings.ca.gov

Safety Information

1. Work environment should be clean, dry, well lit and clear of flammable materials.
2. Do not use outdoors or near water.
3. Do not expose glue gun to rain, moisture or direct sunlight.
4. Keep away from children and pets and store out of reach when not in use.
5. Do not carry glue gun by cord or unplug from outlet by pulling electrical cord.
6. Disconnect glue gun when not in use.
7. Glue gun is on when plugged in. Do not leave unattended.
8. Do not use hot melt glue to replace structural fasteners.
9. Do not use extension cords.
10. Do not use any material other than recommended glue sticks.
11. Avoid accidental discharge. Do not touch glue stick or trigger unless intending to dispense glue.
Feeding or pushing glue stick with too much force into heated gun may cause hot glue to be unexpectedly expelled from nozzle or to flow back from inlet tube.
12. Allow glue gun to cool completely before storing.
13. Save these Safety Instructions for future reference.

Operating Instructions

1. Plug into 120V electrical outlet.
2. Insert 0.27" diameter mini glue stick into back of glue gun through the feeder tube.
3. Allow glue gun to heat for approximately 5 minutes.
4. Squeeze trigger to dispense glue. More glue is dispensed by squeezing trigger repeatedly. Continue glue flow by adding additional glue sticks. Note: Requires approximately 2 glue sticks for initial start up.
5. Immediately press surfaces to be bonded together.
6. Do not pull glue sticks from glue gun. If changing glue, feed remainder of glue stick through glue gun.
7. Unplug after use and allow glue gun to cool completely before storing.

Dual Temp Glue Gun: Use High Temperature for Strong Bonding like Wood, Plastic, Metal, Glass and more. Use Low Temperature for Delicate Materials like Floral, Fabric, Foam, Jewelry and more.

Troubleshooting

Glue gun will not heat up: Make sure glue gun is plugged into a 120V electrical outlet. If glue gun still does not work, the internal fuse of the glue gun may be blown and the glue gun is not repairable. Do not use.

Glue backs up at inlet tube: Glue sticks may be the wrong size. Use only the recommended 0.27" diameter mini glue sticks. Note: Do not elevate front of glue gun. Always use side stands or attached stand.

CAUTION

Do not touch heated glue gun nozzle or melted glue; temperature can reach 380°F. If accidental contact occurs, do not remove glue. Immediately put burned area into cool water. Always wear protective clothing, safety glasses, gloves, long sleeve shirt, and long pants. Keep away from flammable materials.

Manufacturer assumes no responsibility for consequential or indirect damages from the use of this product. For medical emergencies only, call 800-420-7186.